



Software with interface (USB), cables and power supply

CL005C

### Function

Intended for communication between the sensors and the computer, through the USB communication port.

